

Additional Information

For: CP0.5 High-Pressure Female Check Valves

Application / Installation / Operation

Application: Flow is free flowing in one direction and therefore is blocked in the opposite direction.

Installation: Connect the actuator to port A and then connect the pressure flow to port B.

Operation: These valves allow flow from port B to port A and block the flow in the opposite direction

Symbol Drawing

