

## Additional Information

### For: CP6 High-Pressure Male Check Valves

#### Application / Installation / Operation

**Application:** Flow is free flowing in one direction and therefore is blocked in the opposite direction.

**Installation:** Connect the actuator to port A and then connect the pressure flow to port B.

**Operation:** These valves allow flow from port B to port A and block the flow in the opposite direction

#### Symbol Drawing

