

## **Additional Information**

For: Ferro Relief Valve 3/4"

## **Application**

The PR series Hydraulic Pressure Relief Valves act as a part of the control systems. When the system gets over loaded, the Pressure Relief Valve opens and the flow comes from the pump, it is lead directly into the hydraulic reservoir. They used to limit the pressure inside of the Hydraulic circuits.

## **Symbol Drawing**

