


### Additional Data/Spec Sheet

LP Brass Adapter Fittings – NPT Male Hex Head Plug

## 218P Hex-Head Plug



Part Number	Pipe Thread
218P-2	1/8
218P-4	1/4
218P-6	3/8
218P-8	1/2
218P-12	3/4



### Hex-Head Plug 218P

PART NO.	PIPE THREAD	C HEX	L
218P-2	1/8	7/16	.560
218P-4	1/4	9/16	.747
218P-6	3/8	11/16	.780
218P-8	1/2	7/8	.970
218P-12	3/4	1-1/16	1.054

## Assembly Instructions

### Straight Fittings

1. Hand tighten external thread into internal thread
2. Tighten an additional 2 turns with a wrench up to 1/2" male pipe thread.
3. Above 1/2" 1 1/2 to 2 1/2 turns.