

## **Additional Data/Spec Sheet**


LP Brass Adapter Fittings - NPT Male x NPT Female Needle Valve

## Needle Valve NV108P


Female Pipe to Male Pipe \*Provided with Pin Handle

Temperature Range: -45° to +250° F





PART NO.	PIPE Thread	н	L	М
NV108P-2*	1/8	1.50	1.36	1.25
NV108P-4	1/4	1.38	1.56	1.61



## Needle Valves Installation Instructions

Series NV valves should always be installed with the pressure against the seat. Refer to drawing to determine correct direction of flow.