

### Additional Data/Spec Sheet



LP Brass Adapter Fittings – NPT Female x NPT Female Reducing Socket

## 208P Reducer Coupling



Part Number	Pipe Thread 1	Pipe Thread 2
208P-4-2	1/4	1/8
208P-6-4	3/8	1/4
208P-8-4	1/2	1/4
208P-8-6	1/2	3/8
208P-12-6	3/4	3/8
208P-12-8	3/4	1/2

### 208P Reducer Coupling



Part No.	1 Pipe Thread	2 Pipe Thread	C Hex.	L	Flow Dia. D
208P-4-2	1/4	1/8	3/4	0.97	0.339
208P-6-4	3/8	1/4	7/8	1.16	0.441
208P-8-4	1/2	1/4	1-1/16	1.28	0.441
208P-8-6	1/2	3/8	1-1/16	1.38	0.571
208P-12-6	3/4	3/8	1-3/8	1.32	0.571
208P-12-8	3/4	1/2	1-3/8	1.50	0.703

### Assembly Instructions

#### Straight Fittings

1. Hand tighten external thread into internal thread
2. Tighten an additional 2 turns with a wrench up to 1/2" male pipe thread.
3. Above 1/2" 1 1/2 to 2 1/2 turns.



[www.fluidco.co.za](http://www.fluidco.co.za) *Make it Happen!*