



LP Brass Adapter Fittings – NPT Male x NPT Male Hex Reducing Nipple



Hex Nipple Reducers 216P

PART NO.	1 PIPE THREAD	2 PIPE THREAD	C HEX	L	FLOW DIA. D
216P-4-2	1/4	1/8	9/16	1.19	.220
216P-6-2	3/8	1/8	11/16	1.22	.220
216P-6-4	3/8	1/4	11/16	1.41	.314
216P-8-4	1/2	1/4	7/8	1.62	.314
216P-8-6	1/2	3/8	7/8	1.62	.440

Hex Nipple Reducers 216P



Part No.	1 Pipe Thd	2 Pipe Thd	C Hex	L	Flow Dia. D
216P-4-2	1/4	1/8	9/16	1.19	.220
216P-6-2	3/8	1/8	11/16	1.22	.220
216P-6-4	3/8	1/4	11/16	1.41	.314
216P-8-4	1/2	1/4	7/8	1.62	.314
216P-8-6	1/2	3/8	7/8	1.62	.440
216P-12-8	3/4	1/2	1-1/16	1.80	.564

216P

Hex Nipple Reducers



Part Number	Pipe Thread 1	Pipe Thread 2
216P-4-2	1/4	1/8
216P-6-2	3/8	1/8
216P-6-4	3/8	1/4
216P-8-4	1/2	1/4
216P-8-6	1/2	3/8
216P-12-8	3/4	1/2

Assembly Instructions

Straight Fittings

1. Hand tighten external thread into internal thread
2. Tighten an additional 2 turns with a wrench up to 1/2" male pipe thread.
3. Above 1/2" 1 1/2 to 2 1/2 turns.